

## CHEVROLET

| Vehicle              | Positive Wire | Ground | Location                                                                   |
|----------------------|---------------|--------|----------------------------------------------------------------------------|
| Avalanche 06-16      | Light Blue    | Black  | Rear Driver Door C Pillar                                                  |
| Aveo 06-10           | Light Blue    | Black  | Center Hatch Panel                                                         |
| Blazer 19-21         | White         | Black  | Hatch Panel                                                                |
| Bolt 22              | Brown/Yellow  | Black  | Center Hatch Panel                                                         |
| Bolt 17-21           | Brown/Yellow  | Black  | Hatch Panel Boot                                                           |
| Camaro 11-13         | White         | Black  | Under Rear Passenger Window.<br>Wires In Plug Behind Seat Belt<br>Assembly |
| Camaro 14-16         | White         | Black  | Behind Trunk Liner<br>Passenger Side                                       |
| Camaro 17-21         | Violet/White  | Black  | Under Trunk Lining                                                         |
| City Express         | Red           | Black  | Rear Pass Door Boot                                                        |
| Colorado 17-21       | Violet/Brown  | Black  | 2 Screws                                                                   |
| Corvette 14-19       | Violet/White  | Black  | Remove Trim Around<br>Passenger Tail Light To<br>Access Harness            |
| Cruze 16-20          | Violet/White  | Black  | Pass C Pillar Roof                                                         |
| Equinox 18-21        | Violet/White  | Black  | Hatch Panel. Behind<br>grommet. Taped with fluid<br>hose                   |
| Express Van 05-21    | Light Blue    | Black  | 2 Phillips                                                                 |
| Impala 14-19         | Violet/Brown  | Black  | Pass C Pillar Roof                                                         |
| Impala 20            | Violet/White  | Black  | Pass C Pillar Roof                                                         |
| Malibu 16-21         | Violet/White  | Black  | Driver C Pillar Roof                                                       |
| Silverado 14-18      | Violet/Gray   | Black  | (2) Screws At Light                                                        |
| Silverado 19-21      | Violet/White  | Black  | Driver Rear Headliner                                                      |
| Sonic Hatch 18-20    | Brown/Yellow  | Black  | 2 Screws At Light                                                          |
| Sonic LT Sedan 15-21 | Brown/Yellow  | Black  | 2 Screws At Light                                                          |
| Sonic Sedan 15-21    | Brown/Yellow  | Black  | Under Light In Trunk                                                       |
| Spark 15-21          | White/Yellow  | Black  | Hatch Panel                                                                |
| Suburban/Tahoe 15-20 | Violet/Brown  | Black  | Rear Headliner Panel                                                       |
| Suburban/Tahoe 21    | Green         | Black  | Rear Headliner Panel                                                       |
| Trailblazer 21       | Brown/Yellow  | Black  | Hatch Panel                                                                |
| Traverse 09-17       | Light Blue    | Black  | Hatch Panel                                                                |
| Traverse 18-21       | Violet/White  | Black  | Hatch Panel                                                                |
| Volt 18-19           | Brown/Yellow  | Black  | Driver Side Hatch Boot                                                     |
| Trax 15-20           | Green         | Black  | Hatch Panel                                                                |